



HOW TO OPERATE YOUR ACTIVE/INACTIVE DOOR


(RIGHT HAND STACKING / OUTWARD OPENING)




HOW TO OPERATE YOUR LEVER HANDLE



1.) To **Open (Main Swing)**: Push handle down at 45°, and push open. (Allow panel to click into panel catch on the adjacent panel.)



2.) To **Close** door pull panel shut to Latch like a typical entry way door.




3.) After latching pull handle **Up** at 45°, well pulling in. Then engage lock with thumb turn 90° clockwise.


HOW TO OPERATE YOUR BI-FOLD HANDLE



1.) Bi-fold handle in **locked** position. (When door is closed)



2.) To **Open** bi-fold, pull handle up 90° and release then push out.



3.) To **Close** bi-fold, in one motion push handle down 90°.